

Portable Digital Luggage Scale


EL910H

User Manual

■ Care and Maintenance

- 1) Wipe the scale with a slightly damp cloth. DO NOT immerse the scale in water or chemical / abrasive cleaning agents.
- 2) DO NOT stress the triangle ring for long time. During travel, keep the scale away from objects with sharp ends (such as toy, stationery etc.), in case that the scale is turned on and consumes battery.
- 3) DO NOT use this scale in strong-magnetic field.
- 4) This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a toy - never allow children to play with this product. Always store the product out of reach from children.


■ At a Glance



⏻/T/▲ : Turn on/off; tare; add value

U/SET/▼ : Switch between units of measurement (lb or kg); target value setting; reduce value

■ Warning Indicators



1. Low battery. Replace the battery.
2. Scale overloaded. Remove your baggage from the scale. (Max. weight: 110lb/50kg)

■ How to Use

1. Weighing

- 1) Loop the scale's durable nylon woven strap through your baggage handle; hook it at the top using the reliable metal connection.
- 2) Press **⏻/T/▲** to turn on the scale.
- 3) When LCD screen displays zero, lift the scale gently and make sure the scale is horizontal and balanced.
- 4) LCD screen displays the weight of your baggage.
- 5) Under weighing mode, press **⏻/T/▲** button 3 seconds to turn off.

Notes:

- Press **⏻/T/▲** button to tare weight before locking. When LCD screen displays zero and "T", it indicates that Tare function works
- Weight over 1kg will be locked on the LCD screen after flashing three times (LCD screen displays "H"). You can press **⏻/T/▲** button to reset the scale to zero and enter weighing mode again.
- Scale will automatically turn off if no operation is taken for 2 minutes.

2. Set Target Value

LCD screen backlight turns red if baggage weight exceeds the target value.

- 1) When the scale is on, press and hold **U/SET/▼** to enter target setting mode.
- 2) Press **⏻/T/▲** to add or **U/SET/▼** to reduce value.
- 3) Press and hold **U/SET/▼** to save the setting.

3. Switch Between Units of Measurement (lb Or kg)

When the scale is on, press **U/SET/▼** to switch between units of measurement (lb or kg). If no operation is taken for 3 seconds, the scale will enter weighing mode.

4. Replace Battery

- 1) Open battery case cover on the back of the scale and take out the battery.
- 2) Install new battery by putting one side of the battery beneath the battery baffle and then pressing down the other side.

Notes:

- Please observe the polarity.
- Please replace battery when LCD screen displays "Lo".
- Use 3V (CR2032) lithium battery